



CENTRAL MARBLE PRODUCTS, INC.

P.O. Box 357

Rice, MN 56367

Local Phone: 320-393-2085

Toll Free: 1-800-422-0356

Website: www.centralmarbleproducts.com

INSTALLATION INSTRUCTIONS FOR CULTURED **MARBLE VANITY TOP**

STEP 1. BEFORE INSTALLATION, CHECK YOUR MARBLE TOP FOR ANY DEFECTS OR FLAWS.

STEP 2. THE CABINET SURFACE MUST BE CLEAN AND LEVEL.

*STEP 3. SET MARBLE TOP ON CABINET TO BE SURE THE TOP FITS PROPERLY. ALSO AT THIS TIME, IF AN ENDSPLASH IS USED, CHECK TO SEE THAT THE ENDSPLASH FITS TO THE MARBLE TOP.

STEP 4. REMOVE MARBLE TOP AND ENDSPLASH (IF USED) FROM CABINET.

STEP 5. APPLY A SILICONE ADHESIVE TO ALL FOUR CORNERS OF CABINET.

STEP 6. RESET MARBLE TOP ON CABINET. BE SURE MARBLE TOP IS IN PROPER POSITION.

STEP 7. APPLY THE SILICONE ADHESIVE TO THE UNFINISHED SIDE OF ENDSPLASH. ADHERE ENDSPLASH TO WALL WHILE POSITIONING IT ON THE MARBLE TOP.

STEP 8. CAULK ALL OPENINGS BETWEEN THE MARBLE TOP AND THE WALL. IF ENDSPLASH IS USED, CAULK SEAM BETWEEN ENDSPLASH AND MARBLE TOP, THEREFORE SEALING THE SEAM AREA.

STEP 9. CAULK SEAM ON UNDERSIDE OF MARBLE TOP BETWEEN THE MARBLE TOP AND THE CABINET.

***NOTE:** IN SOME SITUATIONS, THE MARBLE TOP MAY NEED TO BE SANDED AT THE JOBSITE TO FIT THE WALL. IF THIS DOES HAPPEN, PLACE THE MARBLE TOP ON THE CABINET AND SCRIBE THE AREA THAT NEEDS TO BE SANDED. LAY THE MARBLE TOP ON A SOLID SURFACE AND SAND THE AREA WITH A BELT SANDER, UNTIL THE MARBLE TOP WILL FIT TIGHTLY AGAINST THE WALL. AFTER THIS IS DONE PROCEED WITH STEP 4.

**WEAR EYE PROTECTION AND A FACE MASK FOR
NUISANCE DUST WHEN SANDING OR CUTTING
CULTURED MARBLE PRODUCTS.**



SUPERIOR QUALITY AND SERVICE FOR OVER 30 YEARS



CMBA
central minnesota
builders association