

**INSTRUCTIONS FOR MEASURING AND INSTALLING
CULTURED MARBLE/GRANITE WINDOW SILLS**

MEASURING INSTRUCTIONS:

STEP 1: Measure finished opening for cultured marble/granite sill's overall length, minus 1/4", which will leave 1/8" expansion gap on each end, which is very easily seamed with 100% silicone in matching color.

STEP 2: Measure finished opening for cultured marble/granite sill's overall depth, plus overhang desired, minus 1/8" expansion gap along window frame which is very easily seamed with 100 % silicone in matching color.

INSTALLATION INSTRUCTIONS:

STEP 1: Clean window sill plate thoroughly.

STEP 2: Check opening size and cultured marble/granite sill size. Note--allow 1/8" expansion gap on both ends and at window frame, scribe if necessary, with belt sander.

STEP 3: Clean cultured marble/granite sill of any dust. Apply quarter sized dot of silicone adhesive every 12" on sill plate. Set cultured marble/granite sill down onto plate and press firmly down.

STEP 4: Clean surface of any dust. Apply 1/8" silicone seam to ends and along window frame.

**WEAR EYE PROTECTION AND A FACE MASK FOR NUISANCE DUST
WHEN SANDING OR CUTTING CULTURED MARBLE/GRANITE PRODUCTS**