



# Central Marble Products, Inc.

320-393-2085 FAX: 320-393-4610 TOLL FREE: 1-800-422-0356  
1266 105th Street NW • P.O. Box 357 • Rice, MN 56367



## INSTRUCTIONS FOR MEASURING AND INSTALLING CULTURED MARBLE/GRANITE WINDOW SILLS

### MEASURING INSTRUCTIONS:

**STEP 1:** Measure finished opening for cultured marble/granite sill's overall length, minus 1/4", which will leave 1/8" expansion gap on each end, which is very easily seamed with 100% silicone in matching color.

**STEP 2:** Measure finished opening for cultured marble/granite sill's overall depth, plus overhang desired, minus 1/8" expansion gap along window frame which is very easily seamed with 100 % silicone in matching color.

### INSTALLATION INSTRUCTIONS:

**STEP 1:** Clean window sill plate thoroughly.

**STEP 2:** Check opening size and cultured marble/granite sill size. Note--allow 1/8" expansion gap on both ends and at window frame, scribe if necessary, with belt sander.

**STEP 3:** Clean cultured marble/granite sill of any dust. Apply quarter sized dot of silicone adhesive every 12" on sill plate. Set cultured marble/granite sill down onto plate and press firmly down.

**STEP 4:** Clean surface of any dust. Apply 1/8" silicone seam to ends and along window frame.

**WEAR EYE PROTECTION AND A FACE MASK FOR NUISANCE DUST  
WHEN SANDING OR CUTTING CULTURED MARBLE/GRANITE PRODUCTS**

**Superior Quality and Service for over 40 Years**