



Central Marble Products, Inc.

320-393-2085 FAX: 320-393-4610 TOLL FREE: 1-800-422-0356
1266 105th Street NW • P.O. Box 357 • Rice, MN 56367



INSTALLATION INSTRUCTIONS

FOR CULTURED MARBLE CUSTOM SHOWER PAN

IMPORTANT:

- Read ALL instructions and information before you start installing custom pan.

REQUIREMENTS:

- Make sure floor is level before beginning installation
- Requires a shower drain that can be used with floor liner as well as shower drain that accepts the liner (same type used in tile units)
- Must install liner covering the floor area attaching to the drain and running up the wall studs 8"

STEPS:

- In threshold area, stand a 2x4 treated on its edge and attach to the floor
 - If wood floor use torque screws, if concrete floor use silicone
- Bring the liner up over the top of the 2x4 and attach the liner to the backside of the 2x4
- Take the second treated 2x4 and attach it to the floor and the first 2x4 while pinching the liner in-between the two
- Shower pan will have a $\frac{3}{4}$ " slope on all sides to the drain. The outer edges will have $\frac{3}{4}$ " strip of wood attached to the bottom side. Put mortar mix in-between the wood strip and the drain to fill the hollow areas
- Check shower floor to make sure water will flow to drain
- Finally, attach the cement board to the walls and the threshold area
- Next, see instructions for panel installation

WEAR EYE PROTECTION AND A FACE MASK FOR NUISANCE DUST WHEN SANDING OR CUTTING CULTURED MARBLE PRODUCTS

Superior Quality and Service for over 40 Years