



# CENTRAL MARBLE PRODUCTS, INC

P.O. Box 357

Rice, MN 56367

Local Phone: 320-393-2085

Toll Free: 1-800-422-0356

Fax: 320-393-4610

Website: [www.centralmarbleproducts.com](http://www.centralmarbleproducts.com)

---

---

## Central Marble Product, Inc Installation Guidelines

**Prior to Measure** 1) In most cases area should be in rough stud stage whether remodel or new construction. 2) All walls should be framed and in place prior to measuring. 3) Shower drain should be roughed in 2" drain pipe should be left 2" above rough floor. Installers will set shower drain when they install shower base or pan. 4) If recessed soap/shampoo niches are going to be used area should be between studs or boxed out by contractor.

**Prior to Installation of Shower Base/ Pan or Tub** 1) Floor should be leveled and walls in rough stud stage. 2) AFTER base/pan or tub are installed walls can be sheeted by the contractor with 1/2" sheathing per building code in area of project.

**Prior to installation of Ceiling Panel** 1) If ceiling panel is being used ceiling must be sheeted with 1/2" sheathing. 2) In most cases ceiling panel is installed same day as shower base/pan or tub. 3) IMPORANT Both ceiling and shower based/pan or tub are installed prior to contractor putting sheathing on the wall.

**Prior to Final Installation of Wall Panels** 1) 1/2" sheathing must be installed. 2) Soap/shampoo niches should be cut in sheathing where they are to be installed. 3) It is best to paint a couple inches into the area where the panels will be installed.

\*Extra Trip charges may apply if these guidelines are not followed.

Guidelines faxed or emailed to \_\_\_\_\_ Date \_\_\_\_\_



**SUPERIOR QUALITY AND SERVICE FOR OVER 40 YEARS**

An Affirmative Action Equal Opportunity Employer

